


BLDRV3 - Motor Wiring - 60ST and 80ST Servo Motors


For 3 Phase Servo Motors

60ST-M01330

80ST-M02340



BLDRV3 Motor Driver



Core Colour	Function	BLDRV3
15 Core Small Signal (Encoder and Hall)		
Black	0V	0V
Red	5V	5V
Orange	B+	Enc A
Yellow	A+	Enc B
Grey	U+	Hall
3 Core Big Signal (Phases)		
Black	W	Phase 3
Blue	V	Phase 2
Brown	U	Phase 1

NOTES:

1. Core colours refer to motor extension cables.
2. "Function" column indicates suppliers wiring diag function.